



PROPANE STOVE INSTRUCTIONS

NOTE: It is recommended that you use a long grill lighter to avoid contact with hands. Always use in a well-ventilated area- OUTDOORS PREFERRED!

Install propane tank. Be sure all knobs on the stove are in the OFF position. Open propane valve. Open oven door and remove the bottom panel to light the pilot. Push red button near the bottom/front and hold while lighting the pilot (inside the oven). Once the pilot is lit, continue to hold in the red button for approximately 30-40 seconds. Release the button, if the pilot did not light, repeat steps 5 and 6. With the pilot lit, replace the bottom panel and close the oven door. Proceed to light the center of each burner. Stove will then be ready to use. Adjust flames to desired heat for cooking.

Thank you for choosing Apex Tent and Party

2765 Dow Ave, Tustin Ca 92760

(714) 573-2000